

PANEL ADJUSTMENT ACCESSORIES

To change the panel position, begin by confirming the safety tether is properly attached.

Step 1: Grab the frame with one hand and remove the locking pin with the other hand. Continue to hold the frame while completing Step 2 (see Figure PA-1).



Figure PA-1



Figure PA-2

Step 2: While holding the frame, set the pin aside and pick up the desired frame extension. Press one end of the frame extension onto the horizontal frame pipe (Figure PA-2).

Step 3: Press the other end of the frame extension onto the horizontal base (48") pipe (Figure PA-3). To remove the frame extension, hold on to the horizontal frame pipe and reverse the procedure.




Figure PA-3